



WHEN WELDING IN CORNER POSTS, BE SURE TO SHIM BETWEEN THE CORNER POSTS AND CROSS SUPPORTS TO PROVIDE FREE MOVEMENT OF SLIDE.

ALL BARRELS MUST BE TRIPLE RINSED BEFORE CRUSHING.



BARREL CRUSHER	
NDSU AGRICULTURAL ENGINEERING EXTENSION SERVICE	Page: 1 OF 2
EXTENSION ENGINEER: VERN HOFMAN	ND Plan #3156-1
DESIGNED BY: ROSS A. HAUGBERG	
DRAWN BY: R.A.H. DATE: 9/9/88	SCALE: 1/16" = 1"

Original file for this drawing is in the file drawer.