



OPERATION:

PUSH START: Mill & Take-away motor starts, (#1) AFTER 5 SECOND DELAY FEED AUGER STARTS (#2)

WHEN GROUND FEED BIN IS FULL, THE BIN SWITCH OPENS AND FEED AUGER (#2) STOPS IMMEDIATELY THEN AFTER 30 SECOND DELAY, MILL AND TAKE-AWAY AUGER STOP AUTOMATICALLY.

THERMAL DELAY TUBES

- 1 - 115 NOS
- 1 - 115 C 30

ALLIED RADIO
100 N.W. AVE.
CHICAGO 89 ILL.

WIRING DIAGRAM FOR SEQUENCE STARTING AND STOPPING OF FEED PROCESSING CENTER
NDSU EXT. AGRIC. ENGINEERING
CRG.
3/65
ND 231-2-3