

Liquid Level or Depth Marker for Earthen Runoff Ponds

Shafiqur Rahman

Assistant Professor, Agricultural and Biosystems Engineering, North Dakota State University

Andrew Aakre

Environmental Engineer, Division of Water Quality, North Dakota Department of Health

Karl Rockeman

Environmental Engineer, Division of Water Quality, North Dakota Department of Health

Chris Augustin

Area Extension Specialist/Nutrient Management, Carrington Research Extension Center

What is a liquid level marker and why is it needed?

Liquid level markers or indicators are a simple but important component of a manure storage facility that is required by state regulations (North Dakota Livestock Program Design Manual 5.2). A properly functioning liquid level marker enables the producer to easily determine the storage capacity of the

pond, make management decisions (to pump or not to pump) and record storage conditions of the pond during regular inspections.

Key components of a marker

State and federal regulations require that manure storage have the minimum capability to hold the annual lot runoff and direct rainfall, as well as runoff and rainfall resulting from a 25-year, 24-hour storm or 100-year, 24-hour storm event, depending on the type of livestock (Fig. 1). In addition to the operating storage volume of the pond, freeboard (the vertical distance between the maximum water-holding depth and the overtopping elevation) is required to protect against situations in which extreme runoff may occur.

The typical freeboard distance is a minimum of 1 foot.

The most important marking on the indicator is the maximum operating level, also known as the pump-down or pump-out depth (Fig. 1). This is the level at which the pond is considered at its maximum operating level and needs to be pumped down. At this point, the pond still should be able to contain the rainfall and runoff from a large storm event. The producer may need to consult with the facility’s design engineer to determine this exact elevation.

Many markers also include markings indicating 1-foot storage increments (Fig. 2). These markings are a great way to assist in regular recording of the depth of water in the pond.




Fig. 1. Capacity of a runoff storage pond (not to scale).



(a)



(b)

Fig. 2. Different types of vertical markers at different location of a pond

(photo a by Chris Augustin; photo b courtesy of Dehaan, Grabs and Associates)

Types of markers

Two most common primary markers are vertical and side-slope markers. Vertical markers can be installed directly on the bottom of an earthen storage pond (**Fig. 2**). An advantage of a vertical marker is that it can be seen easily from anywhere around the pond. A disadvantage to the vertical marker is that improper installation during

construction could puncture the pond liner and allow effluent to infiltrate into the soil.

Vertical markers can be constructed of many materials. The marker should be of a long-lasting, durable material that can stand up to the wet conditions and ice movement during the winter. The actual water elevation indicator could be any number of things:

paint a nailed board; an embedded large nail, bolt or pin; a saw cut or notch; or a collar around the post.

Sloping or side-wall markers are another effective way to indicate the water depth in the pond (**Fig. 3**). The typical construction material for side-slope markers is concrete. A very simple version of the side-slope marker could be stakes on the side slope of the pond. For structural



(a)



(b)

Fig. 3. Different types of slope markers

(photo a courtesy of Dehaan, Grabs and Associates; photo b by Chris Augustin)

markers, the important pond levels could be indicated by scoring the concrete, affixing ear tags to the concrete or placing a stake on the side slope of the pond berm. An advantage of a concrete side-slope marker is that it could be used as an access point to the bottom of the pond for maintenance purposes.

However, depending on the size of the pond or marker, these types of markers may not be visible everywhere, and they tend to be more costly than a vertical marker.

The following side-slope ratio information can be used as a guide line to move pond markers along the side slope.

Table 1. Side slope and corresponding vertical distance.

Side slope	For every 1 foot (12 inches) of vertical elevation, you need to move along the side slope this far
2:1	24 inches
3:1	36 inches
4:1	48 inches

Construction

The ideal time to construct the pond marker is during the construction of the pond or when the pond level is low or empty (**Fig. 4**). Installing it then will ensure accuracy and longevity. However, a pond marker may be installed in an active pond in a number of ways, but the installer must take proper care and precautions.

A vertical marker may be constructed outside of the pond, anchored in concrete and placed on top of the ice layer covering the pond in the winter. Take precautions while working on ice. The North Dakota Game and Fish Department recommends ice be 4 inches thick before anyone walks on it (<http://gf.nd.gov/education/ice-brochure.html>). Additionally, an observer needs to be present with a rope ready to assist the marker's installer in case the ice breaks.

As the ice melts, the marker will sink to the bottom of the pond. The marker must remain vertical while the ice melts.

The indicator also may be placed by a long-reach backhoe or track hoe. Important things to remember are:

- Place the marker far enough into the pond so it is not on the pond slope
- Anchor or add enough weight to the indicator so it is not affected by wind or wave action
- Make sure the indicator is positioned vertically in the pond

The best time to install a concrete marker to be placed on the slope is when the pond level has been pumped down. An important thing to remember is that if the pond has a liner, take care to ensure that the installation doesn't damage the liner.

Summary

A large number of effective pond markers are available. What the marker looks like does not matter; the important thing to remember is that the water level in the pond needs to be managed. The pond marker is a great tool that helps producers make the best management decisions for a facility to prevent an unexpected overflow.



Fig. 4. Installation of pond marker when the pond is empty or under construction
(photos courtesy of K2S Engineering)

For more information on this and other topics, see www.ag.ndsu.edu

NDSU encourages you to use and share this content, but please do so under the conditions of our Creative Commons license. You may copy, distribute, transmit and adapt this work as long as you give full attribution, don't use the work for commercial purposes and share your resulting work similarly. For more information, visit www.ag.ndsu.edu/agcomm/creative-commons.

County commissions, North Dakota State University and U.S. Department of Agriculture cooperating. NDSU does not discriminate in its programs and activities on the basis of age, color, gender expression/identity, genetic information, marital status, national origin, participation in lawful off-campus activity, physical or mental disability, pregnancy, public assistance status, race, religion, sex, sexual orientation, spousal relationship to current employee, or veteran status, as applicable. Direct inquiries to Vice Provost for Title IX/ADA Coordinator, Old Main 201, NDSU Main Campus, 701-231-7708, ndsuoaa.ndsu.edu. This publication will be made available in alternative formats for people with disabilities upon request, 701-231-7881.